


# EXPLODED VIEW AND PARTS LIST OF ALL GAS STOVES WITH OVENS

## MODELS: 2175, 3175, 2375, 3375



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2 / 3	73420	GRATE, BLACK PORCELAIN
2	2 / 3	75422	BURNER CAP, BLACK PORCELAIN
3	2 / 3	75421	BURNER BASE
4	2 / 3	75420	BURNER BODY
5	2 / 3	80716	SPILL BOWL, SMALL BLACK PORCELAIN
6	1	72257	2 BR MAIN TOP, STAINLESS STEEL
		72251	3 BR MAIN TOP, STAINLESS STEEL
7	1	75539	MODULATING THERMOSTAT
8	1	75459	2 BR MANIFOLD
		75458	3 BR MANIFOLD
9	2 / 3	74508	TOP BURNER VALVE
10	1	75595	2BR FACEPLATE
		75596	3 BR FACEPLATE
11	1	72419	2 BR PUSH BUTTON IGNITION
		73956	3 BR PUSH BUTTON IGNITION
12	2 / 3	73577	KNOBS
13	1	80052	2 BR PANEL SIDE, BUILT IN LEFT HAND
		80040	3 BR PANEL SIDE, BUILT IN LEFT HAND
14	1	80047	2 BR PANEL SIDE, GIMBAL LEFT HAND
		80045	3 BR PANEL SIDE, GIMBAL LEFT HAND
15	1	80744	BSI OVEN BURNER ASSEMBLY
16	1	80010	BLACK GLASS OVEN DOOR
		80011	STAINLESS STEEL OVEN DOOR
17	1	80048	2 BR PANEL SIDE, GIMBAL RIGHT HAND
		80044	3 BR PANEL SIDE, GIMBAL RIGHT HAND
18	1	80051	2 BR PANEL SIDE, BUILT IN RIGHT HAND
		80037	3 BR PANEL SIDE, BUILT IN RIGHT HAND
19	1	73044	BROILER PAN
20	1	73045	BROILER PAN INSERT